





# Printing PDF Reports from Optalign® Smart


Version 1.19 Build 1884



First, make sure that the OPTALIGN folder on your ALI 12.700SET USB memory stick is empty (so that you don't inadvertently launch an upgrade upon connecting the memory stick to your Optalign Smart.) Connect the stick to the Optalign Smart via the short ALI 12.503 USB cable, then turn on the computer and bring up the file (or pipe strain wizard report) that you wish to print. Then...

## Printing PDF Reports on a case-by-case basis


Press  , choose Print (5), then choose 'Change printer to PDF file':



Then scroll up to report option you want and press  to send the PDF report to the stick.




You may have to wait as long as three minutes before the report has been generated and saved on the memory stick. Do not remove the stick or press any buttons you get the following screen:





“Report has been saved. Now you can remove pendrive.”


## Setting PDF Files as your Default Printer


If you wish to consistently print reports only as PDFs, then you should change your default printer to ‘PDF File’, as follows:


Press  twice and select ‘Configuration’ (6). Then select ‘Printer configuration’ (5):



With the 'Type' field highlighted in the Print configuration screen, press , then scroll up or down to highlight PDF file:



With 'PDF file highlighted, press  and confirm that the Type now says 'PDF file':



From now on every time you select Print, the report will automatically be generated as a PDF file unless you change to a different printer as described previously. 